



Dependable Wi-Fi coverage for home or business

## **IQ WIFI 6 OVERVIEW**

- 4- Whats included in the box
- 5- IQ WIFI overview: exterior
- 6- IQ WIFI 6 overview: labels
- 7- Choose your installation type
- 8- Evaluating network coverage

## **INSTALLING THE IQ WIFI 6**

- 10- Connecting the wires
- 11- Setting up the network
- 12- Connecting to the network

## **MANAGING IQ WIFI 6 FROM IQ PANEL**

- 14- Connecting additional agents
- 15- Software updates
- 16- Renaming your network name (SSID)
- 17- Creating a guest network
- 18- Testing your speed
- 19- Rebooting IQ WIFI 6 mesh
- 20- Renaming controller or agents
- 21- Viewing connected devices

## **MANAGING IQ WIFI 6 FROM WEB**

### **INTERFACE**

- 23- Connecting additional agents from web
- 24- Software updates from web
- 25- Renaming default network name (SSID)
- 26- Creating a guest network from web
- 27- Renaming controller or agents from web
- 28- Viewing connected devices from web
- 29- WAN settings
- 30- Connection type
- 31- LAN settings
- 32- DHCP server
- 33- DHCP reservation
- 34- How to change admin password

## **TROUBLESHOOTING**

- 36- Sequence to restart your network

- 37- Controller and agents do not sync
- 38- You can't login into the IQ WIFI 6
- 39- How to troubleshoot network connectivity issues

## **SPECIFICATIONS**


- 42- Specifications




# **IQ WIFI 6 OVERVIEW**



IQ WIFI 6



Power Supply



Ethernet Cable



QR code sticker

## SUPPORT



## QUESTIONS?

Contact us at  
855-4QOLSYS  
Or email us at

[intrusion-  
support@tycoint.com](mailto:intrusion-support@tycoint.com)





## ABOUT THIS GUIDE

This document outlines the basic hardware specifications and software directions to install and customize the IQ WIFI 6. Note that the information presented is not comprehensive, but is specifically dedicated to those menus, features, and systems accessible solely to those with the proper installation code. The information contained is confidential and proprietary, and is solely owned by Johnson Controls. Any reproduction, modification, or distribution without permission is strictly prohibited.

## FRONT



### LED Status Lights

-  Error
-  Internet connected
-  Broadcasting wirelessly
-  Power on

## BACK



### Reset Button

Short press: restart  
Press/hold 15 sec:  
Factory Default

### DC-IN

Power Supply

### LAN

Local Area Network  
(Network out)

### WPS


Once this button has been pushed you have 2 minutes to push the **WPS button** on a corresponding Wi-Fi device to connect it to the network

### WAN

Wide Area Network  
(Internet in)

The label on the bottom of IQ WIFI 6 shows the device's MAC address and serial number.

The packaging also includes a QR code that can be scanned by a smartphone camera for easy setup



*Label on the bottom of each unit*



*QR code included in the box*



## You can set up the IQ WIFI 6 in either of these ways:


As the only wireless network on the premises:



Great for:


- Improving connectivity for ALL Wi-Fi devices on the network
- Offering support for the entire network

In parallel with an existing wireless network:



Great for:

- Keeping the security and smart-home devices private/hidden from the rest of the Wi-Fi connected devices on the network
- Making online/remote support easier as only known/authorized devices should be connected
- Ensuring better connectivity for dealer supported devices




1 unit covers up to  
**1,500 sq ft**

Add up to 8 units


If a single IQ WIFI 6 does not cover the location as desired, you can add up to eight (8) additional nodes to eliminate dead spots and boost overall network performance.\*

*\*IQ WIFI 6 will not increase the speed coming from the customer's ISP (Internet Service Provider) but can ensure the customer is getting the best coverage throughout their location. Please note that not all buildings are the same, and building materials, wireless interface, and other factors can limit Wi-Fi range.*

# **INSTALLING THE IQ WIFI 6**




1. Plug the barrel jack end of the power supply into the “DC-IN” port
2. Connect the provided ethernet cable into the “WAN” port



MODEM\*

3. Connect the opposite end of the provided ethernet cable into the “ETHERNET” port on the modem\*.




4. Plug in your power supply to the wall outlet. System may take up to 3 minutes to power up.

*\*Please note: If you are installing IQ WIFI 6 to run in parallel to the customer’s primary network, plug the ethernet cable into an available port on the customer’s existing router*




5




Once the IQ WIFI 6 has powered up completely, the power LED will stop flashing. Activate WPS on IQ Panel. (*Open settings tray, touch settings, advanced settings, type valid code, choose WI-FI.*)

6



Touch "WPS Push Button"

7



Touch "CONNECT"

8



Press the physical WPS button on IQ WIFI 6

9



IQ Panel will confirm when connection is complete. (If, fails repeat from step 5)

*\*Please note: If you prefer to connect to IQ WIFI 6 manually from IQ Panel choose Network Name (SSID) IQ WIFI 6 XXXXXX (the "X" represents the MAC address printed on the label located on the bottom of the IQ WIFI 6). The default password is the serial number printed on the bottom label of the IQ WIFI 6.*

## Wired Connection:

- Connect your laptop to the IQ WIFI 6 via the LAN port on the back of the controller or agent LAN port.
- Open up a web browser (chrome recommended) and type in the following:
  - \\192.168.105.1 (default gateway address)

## Wireless Connection:


- The default SSID is "IQ WIFI 6 XXXXXX" and "IQ WIFI 6 XXXXXX 5G". (XXXXXX is the last 6 digits of the MAC address of the IQ WIFI 6)
- Using the QR code sticker you can auto connect to the default Network Name (SSID)
- WPS mode is also supported for wireless connection.

## Default User Name:

- admin

## Default Password:


- The S/N number printed on the bottom of the IQ WIFI 6 is the default password. Note: Passwords are case sensitive



# **MANAGING IQ WIFI 6 FROM IQ PANEL**

You may choose to improve the WIFI network by adding additional “agents” to the network (up to 7). Agents must be within range of IQ WIFI 6 in order to sync wirelessly.


1



*Example of where controllers and agents may be placed for best performance.*

Choose your location to maximize your mesh WI-FI network. Ensure desired location has an available power outlet.


2



Connect both ends of the power supply to an available outlet.\*

*\*You may choose to connect your agents power close to your controller during the pairing process and move to your desired location once pairing is complete.*

3




Controller

Agent


Once the agent has powered up completely, the power LED will stop flashing. Activate WPS on the controller, then activate WPS on the agent



After the initial setup, update you're IQ WIFI 6 to the latest version of firmware and validate that the IQ WIFI 6 mesh is on the same version of firmware




Open settings tray, touch settings, advanced settings, type valid code, touch installation, devices, WI-FI devices, IQ WI-FI, IQ WI-FI



Touch agent **DEVICES** icon to verify the version of firmware on each added agent.

Touch the **CHECK FOR UPDATE** icon to update the entire IQ WIFI 6 mesh.



Current agent firmware

*\*Note: If adding an additional agent to a preexisting IQ WIFI 6 to improve wireless performance validate that the firmware on the IQ WIFI 6 mesh is the same and if it is not, update.*



SETTINGS

ADVANCED SETTINGS

ENTER CODE (1111, 2222)

INSTALLATION

DEVICES

WI-FI DEVICES

IQ WI-FI

Open settings tray,  
touch settings,  
advanced settings, type  
valid code, touch  
installation, devices, WI-  
FI devices, IQ WI-FI



WI-FI	
2.4GHz	
Eagle_Eye 2.4 - WiFi Network Name (SSID)	
c4c4c4c4 - Password (Network Key)	
5GHz	
Eagle_Eye 5 - WiFi Network Name (SSID)	
c4c4c4c4 - Password (Network Key)	
Activate WPS	
Enable Guest Network	<input type="checkbox"/>
Guest Network is Disabled	
Guest Network 2.4GHz	
Guest 800059 - WiFi Network Name (SSID)	
1912DBC000030 - Password (Network Key)	
Guest Network 5GHz	
Guest 5GHz 800059 - WiFi Network Name (SSID)	
1912DBC000030 - Password (Network Key)	
Installer Settings	
Unpair IQ Wi-Fi	
Forget IQ Wi-Fi network and clear all stored devices and configurations	

Touch the down arrows to make edits to the  
Network Names (SSIDs)



5:36 PM  
Jan 28 2021

Network Name (SSID) Eagle\_Eye 2.4

Password c4c4c4c4

Security Method WPA2 PSK

Show Wi-Fi Via QR Code SHOW

Hidden ☐

SAVE

IQ ROUTER

Enter in a unique **Network Name (SSID)** of  
your choice.


Enter a password that you can remember.

This information will be needed to connect to  
the IQ WIF from any other wireless device.


A Hidden option is disabled by default.  
(Checking this box will hide the Network  
Name (SSID) but still allow connectivity)

*\*Note: By default the IQ WIFI 6 will broadcast two visible Network Names (SSID) for 2.4GHz and 5GHz and two hidden Network Names (SSID) for Security 2.4GHz or 5GHz XXXXXX.*


By default the Guest Network is disabled by default. To enable follow these steps




Open settings tray, touch settings, advanced settings, type valid code, touch installation, devices, WI-FI devices, IQ WI-FI



Scroll down to the Enable Guest Network




Touch the down arrows to make edits to the 2.4/5GHz Guest Network Name (SSID)



Enter a unique Network Name (SSID)

1



Open settings tray, touch settings, advanced settings, type valid code, touch installation, devices, WI-FI devices, IQ WI-FI


2



INTERNET

Touch the **INTERNET** icon


3



Touch the **TEST MY SPEED** button




If you are having problems, or speed is slower than expected, reboot your IQ WIFI 6 Mesh




Open settings tray, touch settings, advanced settings, type valid code, touch installation, devices, WI-FI devices, IQ WI-FI

*\*IQ WIFI 6 will not increase the speed coming from the customer's ISP (Internet Service Provider) but can ensure the customer is getting the best coverage throughout their location. Please note that not all buildings are the same, and building materials, wireless interface, and other factors can limit Wi-Fi range.*




Touch the **REBOOT ALL** button




Open settings tray, touch settings, advanced settings, type valid code, touch installation, devices, WI-FI devices, IQ WI-FI, IQ WI-FI




Touch either the **IQ WI-FI** or **WIFI POINTS** icon



Touch agent **DEVICES** icon on the Controller or Agent you wish to rename.




Touch the down arrow



Type in a unique controller or agent name.

*\*When renaming a controller or agent, please note that the unique name entered can't have any spaces.*

1




Open settings tray, touch settings, advanced settings, type valid code, touch installation, devices, WI-FI devices, IQ WI-FI

2

4  
DEVICES

Touch the **DEVICES** icon



*\*Note: When viewing connected devices, you can manage internet connectivity by unchecking (not internet) the checkbox of a connected device.*

# **MANAGING IQ WIFI 6 FROM WEB INTERFACE**

After all the physical connections are made (see steps 1-4 on page 10), the back-haul mesh activation can be enabled through the web interface, without accessing the IQ Panel settings.

1

https://192.168.105.1

From Chrome go to 192.168.105.1

2



## Authorization Required

Please enter your username and password.

Username

Password

Login

Clear



Login with default user name and password:

Username: admin

Password: XXXXDBC0000XX

3

NETWORK

WIFI MESH

ADVANCED

STATIC LEASES

PORT  
FORWARDING

Navigate to  
**NETWORK** tab and  
select **WIFI MESH**

4

## Wifi Mesh

Basic

Device Role

Controller

EasyMesh On-board

Connect a New Mesh Device (Wifi will select the back-haul band automatically)

Optimize Mesh Network

Optimize Mesh Network (It will take a few minutes)

Runtime Topology

Display Mesh Network Map

Touch the **Connect a New Mesh Device** to  
trigger WiFi back-haul band automatically.

5

Within 2 minutes press the WPS button on an  
additional IQ WIFI 6.

A software update can be done manually after downloading an updated version of firmware from the dealer site.

1

https://192.168.105.1

From Chrome go to 192.168.105.1

2

**Golsys**

**Authorization Required**

Please enter your username and password.

Username

Password



Login with default user name and password:

Username: admin

Password: XXXXDBC0000XX

3

**SYSTEM**

**CHANGE  
PASSWORD**

**FIRMWARE  
UPGRADE /  
BACKUP  
SETTINGS**

**REBOOT**

Navigate to  
**SYSTEM** tab, and  
down to  
**FIRMWARE  
UPGRADE /  
BACKUP  
SETTINGS**

4

**Firmware Upgrade/Backup Settings**

Firmware Upgrade Backup/Restore Settings

Firmware Upgrade:  no file selected

Touch the **Choose File** icon find the downloaded file located on your computer.

5

**Firmware Upgrade/Backup Settings**

Firmware Upgrade Backup/Restore Settings

Firmware Upgrade:  Q0.4.9.bin

Press **Upgrade** icon once the updated file has been selected.

*\*Note: Once a software update has been kicked off, could take as long as 20 minutes plus the time to reboot. LEDs on the IQ WIFI 6 will flash indicating it is updating.*

1

https://192.168.105.1

From Chrome go to 192.168.105.1

2



## Authorization Required

Please enter your username and password.

Username admin

Password



Login with default user name and password:

Username: admin

Password: XXXXDBC0000XX

3

NETWORK

WIFI MESH

ADVANCED

STATIC LEASES

PORT  
FORWARDING

Navigate to  
**NETWORK** tab and  
select **WIFI MESH**

4

Name	EAGLE_EYE 2.4	
Security Mode	WPA2 - Personal	
Password	c4c4c4c4	
Hidden	Disabled	

Scroll down the page to locate the WiFi SSID Settings. Press the **Edit** button to make changes from the default settings.

5

Edit Primary Network(2.4G Hz)

Name	EAGLE_EYE 2.4
Security Mode	WPA2 - Personal
Password (8-64 characters)	c4c4c4c4
Hidden	<input type="checkbox"/>

Enter a unique Network Name (SSID) and password.

*\*Note: Once you have touched the save and apply to the Network Name (SSID) you will need to reconnect to the new unique Network Name (SSID) with the updated password.*

1

https://192.168.105.1

From Chrome go to 192.168.105.1

2



## Authorization Required

Please enter your username and password.

Username admin

Password



Login with default user name and password:

Username: admin

Password: XXXXDBC0000XX

3

NETWORK

WIFI MESH

ADVANCED

STATIC LEASES

PORT  
FORWARDING

Navigate to  
**NETWORK** tab and  
select **WIFI MESH**

4

Enable Guest Network(2.4G Hz)

Scroll down to WiFi Settings, and touch the  
**Enable Guest Network (2.4GHz or 5GHz)**

5

Name	Guest 800092	
Security Mode	WPA2 - Personal	
Password	1912DBC000049	
Hidden	Enabled	

Touch the **Edit** icon and create a unique Network  
Name (SSID) and password.



1

https://192.168.105.1

From Chrome go to 192.168.105.1

2



## Authorization Required

Please enter your username and password.

Username

Password

Login Clear



Login with default user name and password:

Username: admin

Password: XXXXDBC0000XX

3

## Wifi Mesh Device

Warning: There are unsaved changes that will be lost while rebooting!

Name	Role
Controller-800057OFFICE	Controller
Agent-800048BASEMENT	Agent
Agent-80008AMASTER	Agent
Agent-80003EFAMILYCOL	Agent

Scroll down on the home page to locate the **WiFi Mesh Device** section and in the **Name** view, enter a unique controller or agent names

4

Save and Apply

Clear

Touch the Save and Apply


*\*Note: Controller and agent unique names can't support spaces*

1

https://192.168.105.1

From Chrome go to 192.168.105.1

2




### Authorization Required

Please enter your username and password.

Username

Password



Login with default user name and password:  
Username: admin  
Password: XXXXDBC0000XX

3

NETWORK

WIFI MESH


ADVANCED

STATIC LEASES

PORT FORWARDING

Navigate to **NETWORK** tab and select **ADVANCED**

4



Navigate to LAN (Local Area Network)

5

### Connected Device

Hostname
android-2ea0f6dee24fca70
Nates-MBP
Nates-iPhone
android-f3cd04c815afd744

Scroll down to **Connected Devices** to view  
Hostname, IPv4 -Address, Lease time remaining,  
Interface, RSSI, Uplink node, and SSID

JOHNSON CONTROLS CONFIDENTIAL AND PROPRIETARY

PAGE 28 OF 44

1

https://192.168.105.1

From Chrome go to 192.168.105.1

2



## Authorization Required

Please enter your username and password.

Username

Password



Login with default user name and password:

Username: admin

Password: XXXXDBC0000XX

3

**NETWORK**

WIFI MESH

**ADVANCED**

STATIC LEASES

PORT  
FORWARDING

Navigate to  
**NETWORK** tab and  
select **ADVANCED**

4



Navigate to WAN (Wide Area Network)

5

The screenshot shows the WAN settings page. The 'Connection Type' dropdown menu is open, showing options: 'Static address', 'DHCP client' (selected), and 'PPPoE'. The status information on the right includes: Uptime: 6d 0h 52m 58s, MAC-Address: 3C:31:78:80:00:91, RX: 86.32 MB (4533194 Pkts.), TX: 275.56 MB (1235939 Pkts.), and IPv4: 192.168.1.66/24.

Scroll down and click on **Connection Type** to  
select the proper ISP

**PPPoE** is a **connection** protocol (mainly for xDSL **connections**). Using that protocol a PC can **connect** to a network **and** receive an IP. PPPoE is a way to encapsulate network traffic, based on credentialed access (i.e. username and password).

**Static IP** means that regardless of the **connection method**/request the same Network Interface Card (PC) will be issued one, pre-defined IP that will never change.

**DHCP** is a way for a network to allocate unique IP addresses to the devices (i.e. computers and smartphones, etc.) within it so that traffic can be delivered back-n-forth without confusion.

1

https://192.168.105.1

From Chrome go to 192.168.105.1

2



## Authorization Required

Please enter your username and password.

Username

Password

Login

Clear



Login with default user name and password:

Username: admin

Password: XXXXDBC0000XX

3

NETWORK

WIFI MESH

ADVANCED

STATIC LEASES

PORT  
FORWARDING

Navigate to  
**NETWORK** tab and  
select **ADVANCED**

4



Navigate to LAN (Local Area Network)

5

Connection Type

Really switch protocol? ☒ Switch protocol

IPv4 address

IPv4 netmask

After changing LAN IP (it may take about 2 ~ 3 minutes), please reconnect LAN client devices (e.g. NB, mobile phone) and access to Web GUI with new IP.

Scroll down to **IPv4 address** to change the gateway (router) address.

1

https://192.168.105.1

From Chrome go to 192.168.105.1

2



## Authorization Required

Please enter your username and password.

Username

Password



Login with default user name and password:

Username: admin

Password: XXXXDBC0000XX

3

## NETWORK

WIFI MESH

ADVANCED

STATIC LEASES

PORT  
FORWARDING

Navigate to  
**NETWORK** tab and  
select **ADVANCED**

4



Navigate to LAN (Local Area Network)

5

## DHCP Server


Starting IP Address

Number of IP Address

Scroll down to **DHCP Server** to change the  
DHCP settings.



*\*Note: DHCP server default settings support up to 150 addresses beginning at 192.168.105.100 through 192.168.105.250*

1



From Chrome go to 192.168.105.1


2

  
**Authorization Required**  
Please enter your username and password.  
  
Username   
  
Password   
  
   
  
  
  
Login with default user name and password:  
Username: admin  
Password: XXXXDBC0000XX

3


**NETWORK**  
  
WIFI MESH  
  
ADVANCED  
  
**STATIC LEASES**  
  
PORT FORWARDING  
  
Navigate to **NETWORK** tab & **STATIC LEASES**

4




Enter a **Hostname** for the connected device

5



Use the dropdown to select the **MAC-Address** of the connected device.

6



Use the dropdown to select the **IPv4-Address** and touch **Save & Apply**.

*\*Note: **DHCP** Servers support something called a “**DHCP Reservation**”, which essentially allows you to provide a pre-set IP **address** to a specific client based on it's physical **MAC address**. This means that the device will always get the same IP **address** and it will never change.*

1

https://192.168.105.1

From Chrome go to 192.168.105.1

2



**olsys**

**Authorization Required**

Please enter your username and password.

Username

Password

 Login  Clear

**olsys**  
QUALITY OF LIFE

Login with default user name and password:  
Username: admin  
Password: XXXXDBC0000XX

3

**SYSTEM**

**CHANGE PASSWORD**

**FIRMWARE  
UPGRADE /  
BACKUP  
SETTINGS**

**REBOOT**

Navigate to **SYSTEM**  
tab and touch  
**CHANGE PASSWORD**

4

**Change Password**

Changes the administrator password

Password

Confirmation

Enter a unique password that you can remember

5

**Save & Apply** **Clear**

Touch the **Save & Apply** icon

*\*Note: Default username is admin and default password is the serial number printed on the bottom of IQ WIFI 6.*



# TROUBLESHOOTING

When you restart your network, follow this sequence:

1. Turn off *and* unplug the modem.
2. Turn off the IQ WIFI 6.
3. Plug in the modem and turn it on. Wait two minutes.
4. Turn on the IQ WIFI 6 and wait two minutes.

If you are experiencing difficulty syncing the controller and the agent, we recommend that you move the agent into the same room as the controller during the sync. Then move the agent to a different location.

To sync the controller and the agent:

1. Place the agent in the same room as the IQ WIFI 6. Use this agent location only during the sync process.
2. Connect the agent to a power source.
3. Wait for the agent power LED to light solid GREEN.
4. Press the WPS button on the controller and then within two minutes, press the WPS button on the agent.
5. Wait for the agent internet LED to light solid GREEN. The agent WiFi LED will slowly blink GREEN when communicating.
6. Move the agent to a new location and connect the agent to a power source.
7. At the new location, check the agent power LED and make sure it is solid GREEN.  
If the agent error LED lights up RED, make sure you are within range and try again.

Make sure that your computer or IQ Panel is connected to the IQ WIFI 6 network. If you do not want to use a WiFi connection, you can connect your computer to the IQ WIFI 6 with an Ethernet cable.

If you changed the admin password and you forgot what it is, reset the IQ WIFI 6 back to factory default settings.

Check your network and Internet connections:

1. Make sure that your WiFi-enabled computer or IQ Panel is connected to the IQ network.
2. If you are connected to the IQ network but can not access the Internet, check to see if your Internet connection is working.
3. Launch a web browser from a computer or WiFi device that is connected to the network.
4. Enter the DEFAULT GATEWAY ADDRESS, A login window opens.
5. Enter the IQ WIFI 6 admin username and password.
6. The user name is **admin**. The default password is the S/N printed on the bottom label of the Controller. The user name and password are case-sensitive.
7. The Home Screen is displayed

8. Click NETWORK > ADVANCED tab.

The ADVANCED Home page displays.

9. Check that an IP address is shown for the WAN Internet IPv4 section.

10. If 0.0.0.0 is shown, your IQ WIFI 6 did not obtain an IP address from your Internet service provider (ISP).

If your IQ WIFI 6 cannot obtain an IP address from the ISP, you can force your cable or DSL modem to recognize your new IQ WIFI 6 by restarting your network. For more information, see Sequence to restart your network on page 41.

If your IQ WIFI 6 is still unable to obtain an IP address from the ISP, the problem might be one of the following:

- Your Internet service provider (ISP) might require a login program. Ask your ISP whether they require PPP over Ethernet (PPPoE) or some other type of login.
- If your ISP requires a login, the login name and password might be set incorrectly.

# **SPECIFICATIONS**

Part	Description
Process and Memory	SSoC: MT7621DA (MIPS1004Kc dual-core 880MHz, SPI NOR Flash 64MB) Memory: 128MB DDR3 embedded
Connectors	1 DC Power Jack 2 RJ-45 Connectors
LED and Button	LEDs: 4 Single Color LED Buttons: 1 WPS Button on the side 1 Reset button on the back
Antenna	4 Wi-Fi internal antennas
Power Adapter	Input: 100-240VAC, 50-60Hz, 0.68 Max Output: 1.5A 18.0W
Compliance	FCC
Dimensions (H x W x D)	150mm x 89mm x 57.2mm
Weight	172g
Operating Temperature	0°C - 40°C (32°F - 104°F)
Operating Humidity	10% - 90% RH (non-condensing)
Storage Temperature	-20°C -60°C (-4°F - 140°F)
Storage Humidity	5% - 95% RH (non-condensing)



Network and Software	Notes
Ethernet	LAN and WAN Gigabit Ethernet Ports
Wireless	IEEE 802.11 b/g/n/ax 2.4GHz IEEE 802.11 a/n/ac/ax 5GHz
DHCP	Server, Client
Protocols	IPv4 and IPv6
Guest Network	2.4GHz/5GHz
WiFi EasyMesh Standard	Supported
Ethernet On-Boarding	Supported
Topology Dump	Supported
OTA	Supported
Application	OpenWRT Web GUI Configuration

# Johnson Controls



Conforms to UL Std. S985, 1023. & 1610  
Certified to ULC Sub C1023 & ULC Std S545  
Johnson Controls Inc. proprietary.  
Reproduction without permission is not permitted.

Document#: IQP2-IM-8-20  
Revision Date: 12-16-2020  
Software version: 2.5.0